



Utgåva
1
Issue

Grupp
5
Group
Sida
1
Page

GRUPP 5 Bromsar

INNEHÅLLSFÖRTECKNING

	Sida	Koord
Bromssystem	2	2-A3
• Framhjulsbromsdetaljer	4	2-A5
• Bakhjulsbromsdetaljer 182 Ch-30000 ..	6	2-A7
• Bakhjulsbromsdetaljer 182 Ch 30001- 183	8	2-A9
• Komplettenheter	10	2-A11
• Rörledningar	12	2-A13
• Handbroms 182 Ch-30000	14	2-A15
• Handbroms 182 Ch 30001- 183	16	2-A17

GROUP 5 Brakes

INDEX

	Page	Grid
Brake system	2	2-A3
• Front wheel brakes	4	2-A5
• Rear wheel brakes 182 Ch-30000	6	2-A7
• Rear wheel brakes 182 Ch 30001- 183 ..	8	2-A9
• Complete units	10	2-A11
• Pipe lines	12	2-A13
• Handbrake 182 Ch-30000	14	2-A15
• Handbrake 182 Ch 30001- 183	16	2-A17

GROUPE 5 Freins

TABLE DES MATIERES

	Page	Grid
Système de freins	2	2-A3
• Détails de frein de roue avant	4	2-A5
• Détails de frein de roue arrière 182 Ch-30000	6	2-A7
• Détails de frein de roue arrière 182 Ch 30001- 183	8	2-A9
• Unité complète	10	2-A11
• Canalisations	12	2-A13
• Frein à main 182 Ch-30000	14	2-A15
• Frein à main 182 Ch 30001- 183	16	2-A17

GRUPPE 5 Bremsen

INHALTSVERZEICHNIS

	Seite	Grid
Bremsanlage	2	2-A3
• Vorderradbremse, Einzelteile	4	2-A5
• Hinterradbremse, Einzelteile 182 Ch-30000	6	2-A7
• Hinterradbremse, Einzelteile 182 Ch 30001- 183	8	2-A9
• Kpl.Einheiten	10	2-A11
• Rohrleitungen	12	2-A13
• Handbremse 182 Ch-30000	14	2-A15
• Handbremse 182 Ch 30001- 183	16	2-A17

GRUPO 5 Frenos


INDICE

	Pág	Grid
Sistema de frenos	2	2-A3
• Freno de ruedas delanteras, piezas componentes	4	2-A5
• Freno de ruedas traseras, piezas componentes 182 Ch-30000	6	2-A7
• Freno de ruedas traseras, piezas componentes 182 Ch 30001- 183	8	2-A9
• Unidad completa	10	2-A11
• Conducto de freno	12	2-A13
• Freno de mano 182 Ch-30000	14	2-A15
• Freno de mano 182 Ch 30001- 183	16	2-A17



Sida	Grupp	Bromssystem	Brake system	Illustration Utgåva
2	5			1
Page	Group			5992 Issue

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sets Kit	Anmärkning Notes	
1	-	-	-	-		Framhjulsbromsdetaljer	Front wheel brake		SE SIDA 4	010
2	-	-	-	-		Bakhjulsbromsdetaljer	Rear wheel brake		SE SIDA 6	020
	-	-	-	-		182 CH-30000	components 182 CH-30000			030
	-	-	-	-		Bakhjulsbromsdetaljer	Rear wheel brake compo-		SE SIDA 8	040
	-	-	-	-		182 CH 3001-, 183	nents 182 CH 30001-, 183			050
3	-	-	-	-		Komplettenheter	Complete units		SE SIDA 10	060
4	-	-	-	-		Rörledningar	Pipe lines		SE SIDA 12	070
5	-	-	-	-		Handbroms	Handbrake		SE SIDA 14	080
	-	-	-	-		182 CH-30000	182 CH-30000			090
	-	-	-	-		Handbroms	Handbrake		SE SIDA 16	100
	-	-	-	-		182 CH 30001-, 183	182 CH 30001-, 183			110




VOLVO
KA6992



Sida	Grupp	Framhjulsbromsdetaljer	Front wheel brake components	Illustration Utgåva
4	5			4
Page	Group			8413 Issue

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	—	—	—		Framhjulsbroms, V, kmpl	Front wheel brake, L, cpl	8		004
	1	—	—	—		Framhjulsbroms, H, kmpl	Front wheel brake, R, cpl	8		005
	1	—	—	—	684432-8	*Framhjulsbroms, V	*Front wheel brake, L			006
	1	—	—	—	684433-8	*Framhjulsbroms, H	*Front wheel brake, R			010
2	2	—	—	—		**Hus, inre	**Caliper, inner	8		020
3	2	—	—	—		**Hus, yttre	**Caliper, outer	8		030
4	4	—	—	—		**Gummiring	**Rubber ring	8		040
5	8	—	—	—		**Skruv	**Screw	8		050
6	6	—	—	—	678155-3	**Luftningsskruv	**Air venting screw	2		060
7	6	—	—	—	664456-1	**Gummikåpa	**Rubber cap	5		070
8	8	—	—	—	678141-3	**Tätningssring	**Seal ring	5		080
9	8	—	—	—	678142-1	**Kolv	**Piston	3		090
10	8	—	—	—	678143-8	**Gummimanschett	**Rubber seal	5		100
11	8	—	—	—	678144-7	**Låsring	**Circlip	5		120
12	4	—	—	—	664821-6	**Pinne	**Pin	1		130
13	4	—	—	—	664822-4	**Låsfjäder	**Lock spring	1		140
14	1	—	—	—	275876-1	*Bromsklotssats	*Brake pad kit	1	182 CH-30000	150
	1	—	—	—	272566-1	*Bromsklotssats	*Brake pad kit	5	182 CH 30001- 183. (272534)	160
	4	—	—	—		*Bromsklots	*Brake pad	8		170
15	4	—	—	—	670567-7	*Dämpfjäder	*Damping spring	1		180
16	1	—	—	—	673581-5	Konsol, V	Bracket, L			190
	1	—	—	—	673582-3	Konsol, H	Bracket, R			200
17	1	—	—	—	673773-8	Skyddsplåt, V	Backing plate, L			210
	1	—	—	—	673774-6	Skyddsplåt, H	Backing plate, R			220
18	2	—	—	—		Spindel	Steering knuckle		SE GRUPP 6	230
19	4	—	—	—	965539-2	Skruv	Screw	0 L 63		240
20	4	—	—	—	955535-0	Skruv	Screw	0 L 32		250
21	6	—	—	—	955950-1	Låsbricka	Lock washer	0		260
22	8	—	—	—	950354-1	Mutter	Nut	0		270
23	4	—	—	—	943506-6	Skruv	Screw	0		280
23a	ERF	—	—	—		Justermollenlägg	Shim	0		290
	—	—	—	—	682309-0	*Tj 0,2	*Th 0,2			300
	—	—	—	—	682310-8	*Tj 0,4	*Th 0,4			310
24	2	—	—	—	190279-0	Förskruvning	Screw union	0		320
25	2	—	—	—	18651-0	Bricke	Washer	0		330
26	2	—	—	—		Bromsskiva	Brake disc		SE GRUPP 6	340
	1	—	—	—	273071-1	Reparationssats	Repair kit	1		350





Sida Page	Grupp Group	Bakhjulsbromsdetaljer 182 CH-30000	Rear wheel brake components 182 CH-30000	Illustration Utgåva 2 6972 Issue
6	5			

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
1	1	—	—	—	873728-8	Bakhjulsbroms, V	Rear wheel brake, L	8	010
1	1	—	—	—	873727-4	Bakhjulsbroms, H	Rear wheel brake, R	8	020
1	1	—	—	—	873728-8	•Bromssköld, V	•Backing plate, L		030
1	1	—	—	—	873727-4	•Bromssköld, H	•Backing plate, R		040
2	2	—	—	—	873731-6	•Hjulcylinder	•Wheel unit cylinder	1	050
2	2	—	—	—		••Det se sida 26	••Components see page 26		060
3	2	—	—	—	873747-2	•Packning	•Gasket	3	070
4	4	—	—	—	662518-0	•Skruv	•Screw	3	080
5	4	—	—	—	940155-5	•Låsbricka	•Lock washer	0	080
6	2	—	—	—	873728-2	•Hus	•Housing		100
7	2	—	—	—	940155-5	•Låsbricka	•Lock washer	0	110
8	2	—	—	—	955846-1	•Mutter	•Nut	0	120
9	2	—	—	—	671992-5	•Bromsback, främre	•Brake shoe, forward	3	130
10	2	—	—	—	671993-4	•Bromsback, bakre	•Brake shoe, rear	3	140
11	1	—	—	—	275872-0	•Bromsbeläggssats	•Brake lining kit	1	150
12	4	—	—	—		••Bromsbelägg	••Brake lining	8	160
13	40	—	—	—	191905-5	••Nit	••Rivet	5	170
14	1	—	—	—	673737-3	•Håvarm, V	•Lever, L	4	180
14	1	—	—	—	673738-1	•Håvarm, H	•Lever, R	4	190
15	2	—	—	—	673750-6	•Låsplatta	•Retaining plate	1	200
16	2	—	—	—	673748-6	•Låsfjäder	•Spring plate	1	210
17	2	—	—	—	673742-3	•Tryckstäng	•Push rod	3	220
18	1	—	—	—	673744-9	•Tryckstäng, V	•Push rod, L	3	230
18	1	—	—	—	673743-1	•Tryckstäng, H	•Push rod, R	3	240
19	1	—	—	—	673746-4	•Justermutter, V	•Adjuster nut, L	3	250
19	1	—	—	—	673745-6	•Justermutter, H	•Adjuster nut, R	3	260
20	4	—	—	—	662505-7	•Styrpinne	•Pin	5	270
21	4	—	—	—	662506-5	•Fjäder	•Spring	5	280
22	8	—	—	—	662507-2	•Bricka	•Washer	5	290
23	2	—	—	—	673736-5	•Returfjäder	•Return spring	2	300
24	2	—	—	—	662509-9	•Returfjäder	•Return spring	2	310
25	2	—	—	—		Distansbricka	Spacer washer		320
26	4	—	—	—		Packning	Gasket		330
27	ERF	—	—	—		Justermellanlägg	Shim		340
28	8	—	—	—		Skruv	Screw		350
29	8	—	—	—	940097-9	Bricka	Washer	0	360
30	8	—	—	—	955950-1	Låsbricka	Lock washer	0	370
31	8	—	—	—		Mutter	Nut		380
31	2	—	—	—		Bromstrumma	Brake drum		390
31	1	—	—	—	273171-9	Styrpinnesats	Guide pin kit		400

SE GRUPP 4

SE GRUPP 4

SE GRUPP 4


SE GRUPP 4

SE GRUPP 4

SE GRUPP 4

SE GRUPP 4

SE GRUPP 4



VOLVO
KA 6972




Sida	Grupp	Bakhjulsbromsdetaljer			Rear wheel brake components			Illustration Utgåva	
8	5	182 CH 30001- 183			182 CH 30001- 183			4	
Page	Group							12005 Issue	
Pos. Fig.	Antal/Quantity				Detail nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
1	1	-	-	-		Bakhjulsbroms, V, kompl	Rear wheel braks, L, cpl	8	
	1	-	-	-		Bakhjulsbroms, H, kompl	Rear wheel braks, R, cpl	8	
	1	-	-	-		Bakhjulsbroms, V	Rear wheel brake, L	8	182 CH-32789
	1	-	-	-	1204525-6	Bakhjulsbroms, V	Rear wheel brake, L		ERS AV 1 ST 1204525-6
	1	-	-	-		Bakhjulsbroms, H	Rear wheel brake, R	8	182 CH 32790- 183
	1	-	-	-	1206526-4	Bakhjulsbroms, H	Rear wheel brake, R		(685324)
	1	-	-	-		Bakhjulsbroms, H	Rear wheel brake, R		182 CH-32789
	1	-	-	-		Bakhjulsbroms, H	Rear wheel brake, R		ERS AV 1 ST 1206526-4
	1	-	-	-		Bakhjulsbroms, H	Rear wheel brake, R		182 CH 32790- 183
	1	-	-	-		Bakhjulsbroms, H	Rear wheel brake, R		(685325)
2	2	-	-	-		Hus, inre	Caliper, inner	8	
3	2	-	-	-		Hus, yttre	Caliper, outer	8	
4	2	-	-	-		Gummiring	Rubber ring	8	
5	6	-	-	-		Skruv	Screw	8	
6	2	-	-	-	678165-3	Luftningssskruv	Air venting screw	2	
7	2	-	-	-	664468-1	Gummikåpa	Rubber cap	6	
8	4	-	-	-	664816-6	Tätningssring	Seal ring	8	
9	4	-	-	-	680529-5	Kolv	Piston	3	182 CH-32789
	4	-	-	-	685331-1	Kolv	Piston	3	182 CH 32790- 183
10	4	-	-	-	680531-1	Gummimanschett	Rubber seal	8	
11	4	-	-	-	680532-9	Låsring	Circlip	5	
12	4	-	-	-	678145-4	Pinna	Pin	1	
13	4	-	-	-	678146-2	Låsfjäder	Lock spring	1	
14	1	-	-	-	272587-9	Bromsklotssats	Brake pad kit	5	(272535)
	2	-	-	-		Bromsklots	Brake pad	8	
15	2	-	-	-	684747-7	Mejellanlägg	Spacer	2	1) 182 CH-32789
	2	-	-	-	685332-9	Mejellanlägg	Spacer	2	182 CH 32790- 183
16	2	-	-	-	678147-0	Dämpfjäder	Damping spring	2	ALT 1
16a	2	-	-	-	1212207-3	Dämpfjäder	Damping spring	2	ALT 2
17	1	-	-	-	687368-1	Skyddsplåt, V	Backing plate, L	2,5	ERS AV 1ST 1212114-
	1	-	-	-	1206482-0	Skyddsplåt, V	Backing plate, L	3	(1212114)
	1	-	-	-	687369-9	Skyddsplåt, H	Backing plate, R	2,5	
	1	-	-	-	1206483-8	Skyddsplåt, H	Backing plate, R	3	(1212115)
18	4	-	-	-		Skruv	Bolt	0	SE GRUPP 4
19	4	-	-	-		Fjädrande bricka	Resilient washer	0	SE GRUPP 4
20	4	-	-	-		Mutter	Nut	0	SE GRUPP 4
21	4	-	-	-	943507-4	Skruv	Screw	0	
22	2	-	-	-	676812-1	Bromsskiva	Brake disc	3	
23	2	-	-	-	950045-5	Skruv	Screw	3	
	1	-	-	-	273114-9	Reparationsset	Repair kit	1	
		-	-	-		bakhjulsbroms, V, H	rear wheel brake, L, R		

1) Får ej monteras tillsammans med tid. utl (681456). May not be installed together with early production type (681456). Ne doit pas être monté avec version antérieure (681456). Darf nicht zusammen mit der früh. Ausführung (681456) eingebaut werden. No debe montarse juntamente con prod. ant., (681456).

2) 182 CH-38099, 183 CH-172.





3) 182 CH 38100- 183 CH 173.

5) Vid byte från 687368 och 687369 till 1212114 och 1212115 måste även ankarbult 1212113, skruv 955549 och bricka 941909 monteras. When replacing 687368 and 687369 with 1212114 and 1212115 we would like to point out that anchorage bolt 1212113, screw 95549 and washer 941909 are also required. la vis 95549 et la rondelle 941909 doivent être montés. Werden die Teile 95549 und die Scheibe 941909 montiert werden. Al hacer el cambio de los 687368 y 687369 a los 1212114 y 1212115 deberán montarse los pernos de anclaje 1212113, tornillos 95549 y arandelas 941909.






Sida	Grupp	Komplettenheter	Complete units	Illustration	Utgåve					
10	5				3					
Page	Group				7280 Issue					
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sets Kit	Anmärkning Notes	
VST	HST									
1	1	1	—	—	673768-8	Vakuumbromscylinder	Vacuum brake cylinder	3		010
2	4	4	—	—	941907-8	Fjädrande bricka	Resilient washer	0		020
3	4	4	—	—	955847-9	Mutter	Nut	0		030
4	1	1	—	—	673766-2	Tandemhuvudcylinder	Tandem master cylinder	2		040
5	1	1	—	—	680006-6	Gummiring	Rubber ring	1		050
6	2	2	—	—	955921-2	Fjädrbricka	Spring washer	0		060
7	2	2	—	—	955782-8	Mutter	Nut	0		070
8	2	2	—	—	678237-9	Muff	Connector	0		080
9	1	1	—	—	673767-0	Bromsvätskebehållare	Brake fluid container	3		090
10	1	1	—	—	681069-8	Sil	Filter	0		100
11	1	1	—	—	681060-7	Lock	Filler cap	0		120
12	1	1	—	—	673764-7	Varningsventil	Warning valve	3		130
13	1	1	—	—	679939-1	Kontakt	Contact	2		140
14	1	1	—	—	180666-8	Skruv	Screw	0	182 CH-28579	150
15	1	1	—	—	943629-6	Skruv	Screw	0	182 CH-28580-183	160
15a	1	1	—	—	955893-3	Bricka	Washer	0	182 CH-28579	180
16	665	—	—	—	941906-0	Fjädrande bricka	Resilient washer	0	182 CH-28580-183	190
	760	—	—	—	955825-5	Mutter	Nut	0	182 CH-28580-183	200
	—	800	—	—	943707-0	Gummislang	Rubber hose	0	182 CH-30000	210
	—	570	—	—	943707-0	Gummislang	Rubber hose	0	182 CH-30001-183	220
	—	665	—	—	943707-0	Gummislang	Rubber hose	0	182 CH-28638	230
	—	—	—	—	943707-0	Gummislang	Rubber hose	0	182 CH-28639-30000	240
17	1	1	—	—	943707-0	Gummislang	Rubber hose	0	182 CH-30001-183	250
18	100	100	—	—	680476-9	Backventil	Check valve	2		260
19	4	4	—	—	943707-0	Gummislang	Rubber hose	0		270
20	1	1	—	—	943754-0	Slangklammer	Hose clip	0		280
21	1	1	—	—	943199-0	Nippel	Nipple	0		290
22	1	1	—	—		Bromspedal med monteringsdetaljer	Brake pedal with installation components	0	SE SIDA 20	300
23	1	1	—	—	673760-5	Bromsventil, V	Brake valve, L	2	182 CH-37549	310
	1	1	—	—	677588-6	Bromsventil, V	Brake valve, L	2	182 CH-37550-183	320
	1	1	—	—	673761-3	Bromsventil, H	Brake valve, R	2	182 CH-37549	330
	1	1	—	—	677589-4	Bromsventil, H	Brake valve, R	2	182 CH-37550-183	340
24	1	1	—	—	273090-1	Reparationssats	Repair kit	1		350
25	4	4	—	—	940113-4	Skruv	Screw	0		360
26	4	4	—	—	941907-8	Fjädrande bricka	Resilient washer	0		370
27	1	—	—	—	673863-7	Konsol	Bracket	0		380
28	—	1	—	—	681918-8	Konsol	Bracket	0	182 CH-30608	390
	—	1	—	—				0	ERS AV 1 ST 684569-7	400
	—	1	—	—	684569-7	Konsol	Bracket	0	1 ST 683757-9	410
29	4	—	—	—	955524-4	Skruv	Screw	0	182 CH-30609-183	420
	—	5	—	—	955523-8	Skruv	Screw	0		430
30	4	5	—	—	941907-8	Fjädrande bricka	Resilient washer	0	(940113)	450
31	—	5	—	—	960141-0	Bricka	Washer	0		460
32	1	—	—	—	100159-4	Klammer	Clamp	0	182 CH-37549	470
33	1	—	—	—	940098-7	Skruv	Screw	0	182 CH-37549	480
34	1	—	—	—	942336-9	Fjädrande bricka	Resilient washer	0	182 CH-37549	490
35	—	1	—	—	362281-8	Klammer	Clamp	0	182 CH-28638	500
	—	1	—	—	714529-5	Klammer	Clamp	0	182 CH-28639-183	510
36	—	1	—	—	681912-2	Konsol	Bracket	0	182 CH-30608	520
	—	1	—	—				0	ERS AV 1 ST 684569-9	530
	—	1	—	—	684569-9	Konsol	Bracket	0	1 ST 683757-9	540
37	—	1	—	—	681909-8	Tväraxel	Cross shaft	0	182 CH-30609-183	550
38	—	2	—	—	683757-9	Lagerskål	Bearing cage	0	(678975)	560
39	—	2	—	—	679670-0	Busning	Bushing	3		570
40	—	4	—	—	955512-9	Skruv	Screw	0	182 CH-28999	580
	—	4	—	—	940100-1	Skruv	Screw	0	182 CH-29000-183	590
40a	—	4	—	—	941906-0	Fjädrande bricka	Resilient washer	0	182 CH-29000-183	600
40b	—	4	—	—	955893-3	Bricka	Washer	0	182 CH-29000-183	610
41	—	1	—	—	014446-0	Läring	Circlip	0		620
42	—	2	—	—	955524-4	Skruv	Screw	0		630
43	—	2	—	—	941907-8	Fjädrande bricka	Resilient washer	0		640




VOLVO
MA 7280




Sida	Grupp	Rörledningar	Pipe lines	Illustration	Utgåva					
12	5				3					
Page	Group				8976 issue					
Pos. Fig.	Antal/Quantity				Detail nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	—	—	—	873842-1	Bromsrör	Brake pipe	3		010
2	1	—	—	—	873843-9	Bromsrör	Brake pipe	3		020
3	1	—	—	—	873844-7	Bromsrör	Brake pipe	3		030
4	1	—	—	—	873845-4	Bromsrör	Brake pipe	3		040
5	1	—	—	—	873832-2	Bromsrör	Brake pipe	3		050
6	1	—	—	—	873833-0	Bromsrör	Brake pipe	3		060
7	1	—	—	—	873838-9	Bromsrör	Brake pipe	3		070
8	1	—	—	—	873840-5	Bromsrör	Brake pipe	3		080
9	1	—	—	—	873841-3	Bromsrör	Brake pipe	3		090
10	4	—	—	—	873839-7	Bromsrör	Brake pipe	3		100
11	4	—	—	—	871799-5	Bromssläng	Brake hose	1		110
12	8	—	—	—	942338-9	Fjädrande bricka	Resilient washer	0		120
13	8	—	—	—	984858-4	Mutter	Nut	0		130
14	2	—	—	—	1212309-1	Bromsrör	Brake pipe	3 (873819)		140
15	2	—	—	—	1212370-9	Bromsrör	Brake pipe	3 (873819)		150
16	1	—	—	—	873798-5	Konsol	Bracket	1		160
17	1	—	—	—	873799-3	Konsol	Bracket	1		170
18	3	—	—	—	942895-4	Klammer	Clamp	0		180
19	3	—	—	—	190665-0	Skruv	Screw	0		190
20	1	—	—	—	877810-8	Sextvågsförgrening	Six-way union	3		200
21	1	—	—	—	858244-8	Skruv	Screw	0 (858295)		210
22	1	—	—	—	873834-8	Bromsrör	Brake pipe	3 182 CH-30000		220
23	1	—	—	—	884104-3	Bromsrör	Brake pipe	3 182 CH 30001-183		230
24	1	—	—	—	873835-5	Bromsrör	Brake pipe	3 182 CH-30000		240
25	1	—	—	—	884105-0	Bromsrör	Brake pipe	3 182 CH 30001-183		250
26	2	—	—	—	884327-3	Förskruvning	Screw union	3		260
27	1	—	—	—	873836-3	Bromsrör	Brake pipe	3 182 CH-30000		270
28	1	—	—	—	882084-8	Bromsrör	Brake pipe	3 182 CH 30001-183		280
29	1	—	—	—	873837-1	Bromsrör	Brake pipe	3 182 CH-30000		290
30	1	—	—	—	882085-5	Bromsrör	Brake pipe	3 182 CH 30001-183		300
31	4	—	—	—	877880-5	Klammer	Clamp	0		310
32	3	—	—	—	942895-4	Klammer	Clamp	0		320
33	7	—	—	—	190665-0	Skruv	Screw	0		330
34	2	—	—	—	878201-3	Bromssläng	Brake hose	1		340
35	2	—	—	—	190661-0	Packning	Packring	0		350
36	2	—	—	—	942338-9	Fjädrande bricka	Resilient washer	0		360
37	2	—	—	—	865858-8	Mutter	Nut	0		370
38	1	—	—	—	877840-7	Konsol	Bracket	1		380
39	1	—	—	—	866636-8	Skruv	Screw	0		390
40	1	—	—	—	841908-0	Låsbricka	Lock washer	0		400
41	1	—	—	—	873822-3	Bromsrör	Brake pipe	3 182 CH-30000		410
42	1	—	—	—	1212371-7	Bromsrör	Brake pipe	3 182 CH 30001-183		420
43	1	—	—	—	873823-1	Bromsrör	Brake pipe	3 182 CH-30000		430
44	1	—	—	—	1212372-5	Bromsrör	Brake pipe	3 182 CH 30001-183		440
45	1	—	—	—	18301-2	Klammer	Clamp	0		450
46	1	—	—	—	192400-0	Skruv	Screw	0		460
47	3	—	—	—	121585-4	Klammer	Clamp	0 (18355)		470



VST



HST



VOLVO PARTS
1 050 12010



Sida16Page

Grupp5Group


Handbroms182 CH 30001- 183

Handbroms182 CH 30001- 183

Illustration Utgåva3

10581 Issue

Pos. Fig.	Antal/Quantity				Detail nr Part No	Benämning	Description	Sets Kit	Anmärkning Notes	
	VST	HST								
1	4	4	—	—	877530-8	Bromsback	Brake shoe	3	2)	004
	4	4	—	—	1212183-5	Bromsback	Brake shoe		3)	005
2	2	2	—	—	880835-6	Ankarbult	Anchorage bolt		2)	020
2a	2	2	—	—	1212113-3	Ankarbult	Anchorage bolt		3)	025
3	1	1	—	—	877483-0	Konsol, V	Bracket, L		182 CH-31458	030
	1	1	—	—	887107-3	Konsol, V	Bracket, L		182 CH 31457- 183	040
	1	1	—	—	877482-2	Konsol, H	Bracket, R		182 CH-31458	050
	1	1	—	—	887108-1	Konsol, H	Bracket, R		182 CH 31457- 183	060
4	2	2	—	—	855552-5	Skruv	Screw		2)	070
4a	2	2	—	—	855548-1	Skruv	Screw		3)	075
4b	2	2	—	—	841808-4	Bricka	Washer		3)	07
5	2	2	—	—	877736-1	Bricka	Washer		2)	080
6	2	2	—	—	850385-7	Mutter	Nut		2)	080
7	2	2	—	—	855523-6	Skruv	Screw		0	100
8	2	2	—	—	877525-8	Justeranordning	Stack adjuster		13	110
9	2	2	—	—	877528-2	Hylsa	Sleeve		3	120
10	2	2	—	—	1212200-8	Returfjäder, övre	Return spring, upper			13
	2	2	—	—	1212199-2	Returfjäder, nedre	Return spring, lower			13a
10a	2	2	—	—	1212181-8	Tryckplatta	Pressure plate			136
10b	2	2	—	—	1212182-7	Fjäder	Spring			137
11	1	1	—	—	884863-7	Hävarm, V	Lever, L		3 (877523) 182 CH-31458	140
	1	1	—	—	881118-9	Hävarm, V	Lever, L		3 4)	150
	1	1	—	—	884854-5	Hävarm, H	Lever, R		3 (877522) 182 CH-31458	160
	1	1	—	—	881119-7	Hävarm, H	Lever, R		3 4)	170
	2	2	—	—	1212195-0	Hävarm	Lever		3)	175
12	2	2	—	—	877529-0	Tätning	Seal		182 CH-31458	180
12a	2	2	—	—	881136-1	Bålg	Bellows		182 CH 31457- 183	180
13	4	4	—	—	881843-5	Fixeringsfjäder	Fixation spring		2	200
14	1	1	—	—	1212342-8	Handbromsvajer	Cable		(882127)	215
15	2	2	—	—	875814-6	Hållare	•Retainer		2	220
16	2	2	—	—	877218-0	Bult med säkring	•Bolt with lock		2	230
17	2	2	—	—	884883-5	Låsbricka	Lock washer		0	240
18	2	2	—	—	848152-2	Mutter	Nut		0	250
19	2	2	—	—	877582-0	Bricka	Washer		2	260
20	2	2	—	—	884336-9	Returfjäder	Return spring		2 (877584)	270
21	2	2	—	—	877583-8	Bricka	Washer		2	280
22	2	2	—	—	877837-7	Klammer	Clamp		2	290
23	4	4	—	—	188888-0	Skruv	Screw		0	300
24	1	1	—	—	888112-3	Dregstång	Pull rod		3	310
25	1	1	—	—	880908-9	Hållare	Retainer		3	320
26	1	1	—	—	880907-3	Hjul	Wheel		3	330
27	1	1	—	—	880906-1	Distanshylsa	Spacer sleeve			340
28	1	1	—	—	855525-1	Skruv	Screw		0	350
29	1	1	—	—	850353-3	Mutter	Nut		0	360
30	1	1	—	—	854855-5	Fjäder	Spring		2	370
31	2	2	—	—	841808-4	Bricka	Washer		0	380
32	3	3	—	—	841808-4	Mutter	Nut		0	390
33	1	1	—	—	811124-4	Saxpinnebult	Clevis pin		0	400
34	1	1	—	—	811124-4	Saxpinne	Spit pin		0	410
35	1	—	—	—	888118-5	Handbromsspäkt	Handbrake lever			420
	—	1	—	—	888119-3	Handbromsspäkt	Handbrake lever			430
36	2	2	—	—	853578-9	Bushning	•Bushing		3	440
37	1	1	—	—	854332-2	Handtag	•Handle			450
38	1	1	—	—	880511-1	Bygel	•Brace		1	460
39	1	1	—	—	181030-6	Skruv	•Screw		0	470
40	1	1	—	—	884980-2	Knapp	•Button		3	480
41	1	1	—	—	875848-4	Fjäder	•Spring		3	490
42	1	1	—	—	853465-5	Tryckstång	•Push rod		3	500
43	1	1	—	—	853468-3	Spårhaka	•Pawl		3	510
44	1	1	—	—	180848-2	Nit	•Rivet		0	520



VOLVO PARTS
1 050 10581




Sida	18	Grupp	5	Handbroms	182 CH 30001-. 183	Handbrake	182 CH 30001-. 183	Illustration Utgåva	2
Page		Group						10581 Issue	

Pos. Fig.	Antal/Quantity				Detail nr Part No	Benämning	Description	Sets Kit	Anmärkning Notes	
	VST	HST								
45	1	1	✓	—	665236-8	Gummitätning	Rubber seal	3		004
46	1	1	—	—	653449-8	Spärrsegment	Quadrant	3		005
47	2	2	—	—	955525-1	Skruv	Screw	0		006
48	2	2	—	—	950359-3	Mutter	Nut	0		010
49	1	1	—	—		Hållare	Retainer		SE GRUPP 8	020
50	1	1	—	—	661266-2	Lagerfäste	Bearing anchorage			030
51	2	2	—	—	950021-6	Skruv	Bolt	0		040
52	2	2	—	—	955918-8	Fjäderbricka	Spring washer	0		050
53	1	—	—	—	663967-8	Åxel	Shaft		L 37	060
	1	—	—	—	663718-8	Åxel	Shaft		L 45	070
	—	1	—	—	663968-6	Åxel	Shaft		L 37	080
	—	1	—	—	664719-6	Åxel	Shaft		L 45	090
54	2	2	—	—	653578-9	•Bussning	•Bushing	3		100
55	1	—	—	—	663966-0	Lagerfäste	Bearing anchorage			110
	—	1	—	—	663965-2	Lagerfäste	Bearing anchorage			120
56	1	—	—	—	662998-0	Lagerfäste	Bearing anchorage			130
	—	1	—	—	663013-7	Lagerfäste	Bearing anchorage			140
57	4	4	—	—	955524-4	Skruv	Screw	0 (955656)		150
58	6	6	—	—	955894-1	Bricka	Washer	0		160
59	4	4	—	—	955921-2	Fjäderbricka	Spring washer	0		170
60	2	2	—	—	955828-3	Mutter	Nut	0 (955847)		180
61	1	1	—	—	663185-7	Reglerlänk	Control link	3		190
62	1	1	—	—	955894-1	Bricka	Washer	0		200
63	2	2	—	—	907849-4	Saxpinne	Split pin	0		210
64	1	—	—	—	672978-4	Konsol	Bracket			220
	—	1	—	—	672979-2	Konsol	Bracket			230
65	1	1	—	—		Kontakt	Contact		SE GRUPP 3	240
66	1	1	—	—		Låsbricka	Lock washer		SE GRUPP 3	250
67	1	1	—	—		Mutter	Nut		SE GRUPP 3	260
68	1	1	—	—	663463-7	Plugg	Plug			270

2) 182 CH 38099, 183 CH 172.

3) 182 CH 38100-, 183 CH 173.

4) 182 CH 31457-38099, 183 CH 172.




VOLVO PARTS
1 050 10581



Sida 22 Grupp 5 Vakuumbroms cylinder Vacuum brake cylinder Illustration Utgåva 1
Page Group 6925 Issue

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	—	—	—	673768-8	Vakuumbroms cylinder	Vacuum brake cylinder	3		010
2	1	—	—	—	682077-3	•Filter	•Filter	1		020
3	1	—	—	—	682078-1	•Ljuddämpare	•Silencer			030
4	1	—	—	—	681650-4	•Hållare	•Retainer			040
5	1	—	—	—	681651-6	•Gummikåpa	•Rubber casing	1		050

1




VOLVO
KA 69 25



Sida	Grupp	Tandemhuvudcylinder	Tandem master cylinder	Illustration Utgåva
24	5			
Page	Group			6982 Issue

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	—	—	—	673786-2	Tandemhuvudcylinder	Tandem master cylinder	2		010
2	1	—	—	—		•Hus	•Housing	8		020
3	1	—	—	—	682072-4	•Fjäder	•Spring	3		030
4	2	—	—	—		•Fjädertallrik	•Spring plate	3		040
5	2	—	—	—		•Stödring	•Back up ring	8		050
6	4	—	—	—		•Packning	•Packing	8		060
7	2	—	—	—		•Bricka	•Washer	8		070
8	1	—	—	—		•Kolv	•Piston	8		080
9	1	—	—	—	681654-0	•Skruv	•Screw			090
10	1	—	—	—	682074-0	•Hylsa	•Sleeve			100
11	1	—	—	—	682075-7	•Fjäder	•Spring	3		110
12	1	—	—	—		•Kolv	•Piston	8		120
13	2	—	—	—		•Bricka	•Washer	8		130
14	2	—	—	—		•Packning	•Packing	8		140
15	1	—	—	—	682076-5	•Distansbricka	•Spacer washer			150
16	1	—	—	—		•Låsring	•Lock ring	8		160
17	1	—	—	—		•Packning	•Packing	8		170
18	1	—	—	—	681658-1	•Stoppskruv	•Set screw			180
	1	—	—	—	272125-5	Reparationssats	Repair kit	1		190

①




**VOLVO
KA6982**



Sida	Grupp	Hjulcylinder	Wheel unit cylinder	Illustration Utgåva
26	5			1
Page	Group			6786 Issue

Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
1	1	—	—	—	673731-8	Hjulcylinder	Brake cylinder	1		010
2	1	—	—	—		•Hus	•Housing	8		020
3	2	—	—	—	673733-2	•Kolv	•Plunger	3		030
4	2	—	—	—	673734-0	•Gummipackning	•Rubber packing	S		040
5	1	—	—	—	673735-7	•Fjäder	•Spring	3		050
6	2	—	—	—	662517-2	•Gummikåpa	•Rubber casing	S		060
7	1	—	—	—	678155-3	•Luftningsnippel	•Air venting nipple	1		070
8	1	—	—	—	656456-1	•Gummikåpa	•Dust cap	S		080
	1	—	—	—	273275-8	Reparationssets	Repair kit	1		090

1



VOLVO
KA6786

